


Operation manual

Interface module LRZ 926

RS 232/485 Advanced module



Manufacturer:
LAUDA DR. R. WOBSE GMBH & CO. KG
Laudaplatz 1
97922 Lauda-Königshofen
Germany
Telephone: +49 (0)9343 503-0

E-mail: info@lauda.de
Internet: <https://www.lauda.de>

Translation of the original operation manual
Q4DA-E.13-021, 3, en_US 08/13/2024 © LAUDA 2022
replaces issue V2R6, V1R13

Table of contents

1	General.....	5
1.1	Intended use.....	5
1.2	Compatibility.....	6
1.3	Technical changes.....	6
1.4	Warranty conditions.....	6
1.5	Copyright.....	6
1.6	Contact LAUDA.....	7
2	Safety.....	8
2.1	General safety information and warnings.....	8
2.2	Information about the interface module.....	9
2.3	Personnel qualification.....	9
3	Unpacking.....	10
4	Device description.....	11
4.1	Purpose.....	11
4.2	Structure.....	11
5	Before starting up.....	12
5.1	Installing the interface module.....	12
5.2	Using the module box.....	14
6	Commissioning.....	15
6.1	Contact assignment.....	15
6.1.1	Contact assignment RS 232.....	15
6.1.2	Contact assignment RS 485.....	17
6.2	Software update.....	17
6.3	Module generation.....	17
7	Operation.....	18
7.1	Menu structure.....	18
7.2	Interface functions.....	18
7.2.1	General Information.....	18
7.2.2	Operating rights.....	20
7.2.3	Communication monitoring.....	20
7.2.4	Read commands.....	21
7.2.5	Write commands.....	27
7.2.6	Availability of the interface functions.....	31
7.2.7	Error messages.....	35
7.3	Control and automation software.....	37
8	Maintenance.....	38
9	Faults.....	39

9.1	Alarm.....	39
9.2	Error.....	39
9.3	Warning.....	40
10	Decommissioning.....	41
11	Disposal.....	42
12	Accessories.....	43
13	Technical data.....	44
14	Declaration of Conformity.....	45
15	Index.....	46

1 General

Many types of LAUDA constant temperature equipment have vacant module slots for installing additional interfaces. The number, size and arrangement of the module slots vary depending on the device and are described in the operating manual accompanying the constant temperature equipment. Two additional module slots available as accessories can be fitted to a LiBus module box, which is then connected as an external casing to the LiBus interface on the constant temperature equipment.

This operating manual describes how to install and configure the RS 232/485 interface module (catalog no. LRZ 926).

The RS 232/485 interface is designed for activating constant temperature equipment via the LAUDA command set. The interface functions provided for this purpose are described in the chapters Write commands and Read commands.

1.1 Intended use

The interface module can only be operated as intended and under the conditions specified in this operating manual.

The interface module may only be used in the following areas:

- Production, quality assurance, research and development in an industrial environment

The interface module is an accessory item that is used to control and monitor the LAUDA constant temperature equipment. The interface module is built into the device and connected to the 24 volt supply. It may only be installed in constant temperature equipment that supports the interface provided. Refer to the chapter "Compatibility" in this operating manual for a list of compatible product lines.

Operation of the interface module is also permitted in combination with the LiBus module box (LAUDA catalog no. LCZ 9727). This operating manual also contains a description of how to install and connect up the module box.

Reasonably foreseeable improper use

- Operation on a non-compatible device
- Outdoor operation
- Operation in a potentially explosive area
- Operation after incomplete assembly
- Operation using defective cables or connections or those that do not confirm to standards
- Operation under medical conditions in accordance with DIN EN 60601-1 or IEC 601-1

1.2 Compatibility

The interface module is available as an accessory for the following LAUDA product lines:

- Integral IN
- PRO
- Variocool
- Variocool NRTL



No operation of interfaces of the same type

Only one RS 232/485 type interface can be used for each item of constant temperature equipment. This applies irrespective of the interface operating mode.



No operation of different interfaces

Combining the RS 232/485 interface with a Profibus, Profinet, or CAN interface is not permitted. These interfaces cannot be combined with one another.

1.3 Technical changes


All technical modifications are prohibited without the written consent of the manufacturer. Damage resulting from a failure to observe this condition will void all warranty claims.

However, LAUDA reserves the right to make general technical modifications.

1.4 Warranty conditions

LAUDA grants a standard warranty of one year.

1.5 Copyright

This operating manual was written in German, checked and approved. If the content of other language editions deviates from the German edition, the information in the German edition shall take precedence. If you notice any discrepancies in the content, please contact LAUDA Service, see  Chapter 1.6 “Contact LAUDA” on page 7.

Company and product names mentioned in the operating manual are usually registered trademarks of the respective companies and are therefore subject to brand and patent protection. Some of the images used may also show accessories that are not included in the delivery.

All rights reserved, including those relating to technical modifications and translations. This operating manual or parts thereof may not be modified, translated or used in any other capacity without the written consent of LAUDA. Violation of this may obligate the violator to the payment of damages. Other claims reserved.

1.6 Contact LAUDA

Contact the LAUDA Service department in the following cases:

- Troubleshooting
- Technical questions
- Ordering accessories and spare parts

Please contact our sales department for questions relating to your specific application.

Contact information

LAUDA Service

Phone: +49 (0)9343 503-350

Email: service@lauda.de

2 Safety

2.1 General safety information and warnings



- Read this operating manual carefully before use.
- Keep the operating manual in a place within easy reach of the interface module.
- This operating manual is part of the interface module. If the interface module is passed on, the operating manual must be kept with it.
- This operating manual is applicable in combination with the operating manual of the constant temperature equipment in which the interface module is installed.
- Manuals for LAUDA products are available for download on the LAUDA website: <https://www.lauda.de>
- The warnings and safety instructions in this operating manual must be observed without fail.
- There are also certain requirements for personnel, see ➔ Chapter 2.3 “Personnel qualification” on page 9.

Structure of warnings

Warning signs	Type of danger
	Warning – danger zone.
Signal word	Meaning
WARNING!	This combination of symbol and signal word indicates a potentially dangerous situation that can result in death or serious injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a potentially dangerous situation that can result in material and environmental damage if it is not avoided.

2.2 Information about the interface module

- Always disconnect the constant temperature equipment from the power supply before installing the interface module or connecting interfaces.
- Always take the recommended safety measures against electrostatic discharge before handling interface modules.
- Avoid touching the circuit board with metallic tools.
- Do not start up the constant temperature equipment before installation of the interface module is complete.
- Store any unused interface modules in their packaging in accordance with the specified ambient conditions.
- Use only suitable cables of sufficient length for cable connections.
- Make sure that the protective screen on the cables and connectors complies with EMC regulations. LAUDA recommends using pre-assembled cables.
- Always lay cables correctly so that they do not pose a tripping hazard. Secure the laid cables and make sure that they cannot be damaged during operation.
- Check the condition of the cables and interfaces prior to each operation.
- Immediately clean any soiled parts, in particular unused interfaces.
- Make sure that the signals transmitted via the interface correspond to the permitted operating parameters of the interface module.

2.3 Personnel qualification

Specialized personnel

Only specialized personnel are permitted to install interfaces modules. Specialized personnel are personnel whose education, knowledge, and experience qualify them to assess the function and risks associated with the device and its use.

3 Unpacking



NOTICE! Transport damage

Device damage

- Closely inspect the device for transport damage prior to starting up.
- Never operate a device that has sustained transport damage!



NOTICE! Electrostatic discharge

Material damage

- Always observe safety measures against electrostatic discharge.

Please observe the following installation sequence:

1. Remove the interface module from its packaging.
2. If you want to store the interface module at the installation location, use the outer packaging. This packaging is protected against static charging.
3. After installing the equipment, dispose of the packaging materials in line with environmental regulations, see ↗ “Packaging” on page 42.




If you discover any damage on the interface module, contact LAUDA Service immediately, see ↗ Chapter 1.6 “Contact LAUDA” on page 7.

4 Device description

4.1 Purpose

The RS 232/485 module is designed for installation in constant temperature equipment that supports the serial interface. The RS 232/485 interface allows the user to activate constant temperature equipment via the LAUDA command set (for example, control station).

4.2 Structure



- 1 Cover with holes for fastening screws
- 2 D-Sub socket, 9-pin

The RS 232/485 module is equipped with a serial interface with 9-pin D-Sub socket that incorporates a galvanically isolated optocoupler to ensure electrical isolation and greater immunity to interference. The module is connected to a PC or control station via a 1:1 contacted cable, see Chapter 6.1.1 “Contact assignment RS 232” on page 15.

Fig. 1: RS 232/485 module

5 Before starting up

5.1 Installing the interface module

The interface module is connected to an internal LiBus ribbon cable and inserted into a vacant module slot. The number and arrangement of the module slots vary depending on the device. The module slots are protected by a cover that is screwed onto the casing or attached to the slot opening.



WARNING!
Touching live parts

Electric shock

- Disconnect the device from the power supply before starting any installation work.
- Always observe safety measures against electrostatic discharge.



The module installation description essentially applies to all LAUDA constant temperature equipment; the example diagrams here show the installation of an analog module in constant temperature equipment from the Variocool product line.

Please note that an interface module with a small cover can only be installed in a low module slot. The fitted cover must cover the opening on the module slot completely.

You will require two M3 x 10 screws and a suitable screwdriver to secure the interface module.

Please observe the following installation sequence:

1. Turn off the constant temperature equipment and pull out the mains plug.
2. If necessary, remove the screws from the cover on the relevant module slot. If necessary, use a slotted screwdriver to prise off the cover.




Fig. 2: Removing the cover (schematic diagram)




Fig. 3: Detaching the LiBus ribbon cable (schematic diagram)




Fig. 4: Connecting the interface module (schematic diagram)




Fig. 5: Securing the cover (schematic diagram)

3. Remove the cover from the module slot.
 - The module slot is open. The LiBus ribbon cable is attached to the inside of the cover and is easily accessible.
4. Disconnect the LiBus ribbon cable from the cover.
5. Connect the red plug on the LiBus ribbon cable to the red socket on the circuit board of the interface module. Plug and socket are reverse polarity protected: Make sure that the lug on the plug is aligned with the recess in the socket.
 - The interface module is correctly connected to the constant temperature equipment.
6. Slide the LiBus ribbon cable and the interface module into the module slot.
7. Secure the cover to the casing using two M3 x 10 screws.
 - The new interface on the constant temperature equipment is ready for operation.

5.2 Using the module box




Fig. 6: LiBus module box, catalog no. LCZ 9727

You can extend LAUDA constant temperature equipment by two additional module slots using the LiBus module box. The module box is designed for interface modules with a large cover and is connected to constant temperature equipment via a vacant LiBus socket. The socket on the constant temperature equipment bears the label **LiBus**.

Please observe the following installation sequence:

1. Switch off the constant temperature equipment.
2. Disconnect the cable on the module box from the constant temperature equipment.
 - The module box is disconnected from the power supply.
3. Check which interfaces are already present on the constant temperature equipment and module box.



Observe the information on interface module compatibility. Only install an interface module with the same type of interface if operation with several of these interfaces is permitted.

4. Install the required interface module in the module box. Please read the information on installing the module box in the constant temperature equipment, see chapter "Installing the interface module".
5. Position the module box close to the constant temperature equipment.
6. Connect the cable on the module box to the LiBus socket on the constant temperature equipment.
 - The interfaces on the module box are ready for operation.

6 Commissioning

6.1 Contact assignment



If you have assembled the cables yourself, please note the following:

- Statutory EMC requirements also apply to the cable connections. Use only shielded connection lines with shielded plugs/sockets.
- Reliably isolate all equipment connected to the extra-low voltage inputs and outputs according to DIN EN 61140 to safeguard against dangerous contact voltages. For example, use double or reinforced insulation according to DIN EN 60730-1 or DIN 60950-1.
- Note the contact assignment required in each case, see ↗ Chapter 6.1.1 "Contact assignment RS 232" on page 15 and ↗ Chapter 6.1.2 "Contact assignment RS 485" on page 17.

The RS 232/485 interface is designed as a 9-pin D-Sub socket. The connector can be configured for a 9- or 25-pin connection to a PC or control station according to the contact assignments listed below. The plugs must always be secured with the integral screw connection.

Refer to ↗ Chapter 12 "Accessories" on page 43 for accessory information on assembling connection cables.

6.1.1 Contact assignment RS 232

Systems connected to RS 232 connections use so-called "handshake signals" to transmit status information, which enable the receiving system to stop transmitting data that it can no longer process. The handshake therefore helps protect against data loss.

Status information can be transmitted in two different ways:

- | | |
|--------------------|--|
| Software handshake | - The status information is part of the actual data transfer. A three-wire cable is adequate, while signaling is performed via an additional coding. |
| Hardware handshake | - Status information is transmitted at the same time as the data. Status information is not included in the operating data, but the signaling requires a 7-wire cable for additional signal lines. |

RS 232 with software handshake




Fig. 7: D-Sub socket contacts, 9 and 25-pin

A 1:1 contacted, 3-wire cable (not a null modem cable) is required for an RS 232 connection with software handshake. The operating mode *RS 232 without hardware handshake* must be set on the PC. Contacts should not be connected unless they are needed. The following contact assignment applies, depending on the version of the D-Sub socket on the PC:

Table 1: D-Sub sockets for RS 232 with software handshake

Constant temperature equipment		PC / control station		
Signal	Contact (9-pin)	Contact (9-pin)	Contact (25-pin)	Signal
TxD	2	2	3	RxD
RxD	3	3	2	TxD
GND	5	5	7	GND

RS 232 with hardware handshake

A 1:1 contacted, 7-wire cable (not a null modem cable) is required for an RS 232 connection with hardware handshake. Contacts should not be connected unless they are needed. The following contact assignment applies, depending on the version of the D-Sub socket on the PC:

Table 2: D-Sub sockets for RS 232 with hardware handshake

Constant temperature equipment		PC / control station		
Signal	Contact (9-pin)	Contact (9-pin)	Contact (25-pin)	Signal
TxD	2	2	3	RxD
RxD	3	3	2	TxD
DSR	4	4	20	DTR
GND	5	5	7	GND
DTR	6	6	6	DSR
CTS	7	7	4	RTS
RTS	8	8	5	CTS

6.1.2 Contact assignment RS 485

An RS 485 connection can be implemented using a 3-wire cable; contacts should not be connected unless they are needed. The following contact assignment applies, depending on the version of the D-Sub socket on the connected system:

Table 3: D-Sub socket, RS 485, 9-pin

Signal	Contact
Data A (-)	1
GND (optional)	5
Data B (+)	6




Fig. 8: RS 485 termination



A RS 485 bus always requires a bus termination in the form of a termination network (see Figure) that guarantees a defined standby state in the high-ohm phases of bus operation. This termination network is usually integrated in the insertable PC card (RS 485).

6.2 Software update

Older software installed on constant temperature equipment may have to be updated for the new interface to work.

1. Switch on the constant temperature equipment after installing the new interface.
2. Check whether a software warning appears on the display.
 - Warning 510 - 532 *SW update required* or *SW too old*: Please contact LAUDA Service, see Chapter 1.6 "Contact LAUDA" on page 7.
 - No software warning: Operate the constant temperature equipment as normal.

6.3 Module generation

To see which generation of an interface module is involved, proceed as follows:

1. Switch on the constant temperature equipment after installing the interface module.
2. Press the [Enter key] on the constant temperature equipment to open the menu.
3. On the Integral IN constant temperature equipment, for example, select the → *Device status* → *Hardware version* menu items. On the Variocool constant temperature equipment, for example, select the → *Setup* → *Device status* → *Hardware version* menu items.
 - A list of hardware versions opens.

If the revision number (1) appears in brackets in front of the printed circuit board index, a second generation interface module (with the suffix "Advanced") is installed in the constant temperature equipment.

7 Operation

7.1 Menu structure




The menu only ever shows functions that are available for the current constant temperature equipment.

The menu for configuring the interface is integrated in the main menu of the relevant constant temperature equipment:

All operating units except for the master

Menu → Modules → Serial interface



* Only when operating according to the RS 485 standard.

Fig. 9: RS 232/485 interface menu

7.2 Interface functions

Interface functions such as read and write commands make it possible to read out the current operating parameters of constant temperature equipment and predefine specific settings and process values.

The interface functions supported by this interface are presented briefly below. They are sorted by topic according to the component affected and assigned a unique ID. Depending on the technical configuration of your constant temperature equipment, the number and scope of the interface functions actually available may vary from the list shown here, see chapter "Availability of the interface functions".

7.2.1 General Information

Communication takes place according to the master/slave principle. In order to ensure that a request and response are uniquely assigned to one another, commands can only be sent to the constant temperature equipment once a response to the previous command has been received.

All available read and write commands as well as the meaning of any error messages that may occur are presented below. Note the following information relating to syntax and sequencing when using these commands:

Numerical values are provided in fixed point format; numbers with up to 4 places in front of the decimal point and up to 2 places after the decimal point are permitted:

Table 4: Acceptable data formats

-XXXX.XX	-XXXX.X	-XXXX.	-XXXX	XXXX.XX	XXXX.X	XXXX.	XXXX
-XXX.XX	-XXX.X	-XXX.	-XXX	XXX.XX	XXX.X	XXX.	XXX
-XX.XX	-XX.X	-XX.	-XX	XX.XX	XX.X	XX.	XX
-X.XX	-X.X	-X.	-X	X.XX	X.X	X.	X
-.XX	-.X	.XX	.X				

- Error messages are output with the syntax "ERR_X":
 - ERR = Identification as an error message
 - X = Error number (whole number without leading zero, maximum of 4 digits)
- Space " " and underscore "_" can be used synonymously.

RS 232 protocol

- The interface operates with 1 stop bit, 8 data bits and no parity bits.
- 4 transmission speeds are available for selection: 2400, 4800, 9600 or 19200 baud. 9600 baud is the factory preset.
- Commands from an external source must always end with CR, CRLF or LFCR. The response from the constant temperature equipment always ends with CRLF. Meaning of the abbreviations:
 - CR = Carriage Return, (Hex: 0D)
 - LF = Line Feed, (Hex: 0A)
- In order to ensure that a request and response are uniquely assigned to one another, commands can only be sent to the constant temperature equipment once a response to the previous command has been received.

Example

Example with set point transfer of 30.5 °C to the constant temperature equipment.

PC / control station	Constant temperature equipment
"OUT_SP_00_30.5"CRLF	➔
←	"OK"CRLF

RS 485 protocol

- The interface operates with 1 stop bit, 8 data bits and no parity bits.
- 4 transmission speeds are available for selection: 2400, 4800, 9600 or 19200 baud. 9600 baud is the factory preset.
- RS 485 commands are always preceded by the device address; up to 128 device addresses are available. Device addresses always contain three digits and start with "A": "A000_..." – "A127_..."
- Commands from an external source must always end with CR. The response from the constant temperature equipment always ends with CR.

Example

Example with set point transfer of 30.5 °C to the constant temperature equipment. In this example, the address 15 is used.

PC / control station	Constant temperature equipment
"A015_OUT_SP_00_30.5"CR	➔
⬅	"A015_OK"CR

7.2.2 Operating rights

Valid for Integral IN and Variocool NRTL constant temperature equipment

As soon as a write command is sent to the device via the interface, the interface automatically obtains the operating rights.



If another control section already has exclusive operating rights, writing is not possible and the interface responds with error message 38.

If you subsequently want to operate the device from a different control section, you must first explicitly obtain the relevant operating rights.

Example

If you wish to take over operation and operate the device using its keyboard, you must press the softkey with the lock symbol on the device display and confirm your entry.

Exclusive operating rights

If you wish to prevent any other control section from obtaining operating rights, you have the option of using the command with the ID 34 – setting the timeout value for communication – to secure exclusive operating rights for the interface. The timeout setting must be greater than 0 seconds.

When the timeout is set to a value greater than 0 ➔ Chapter 7.2.3 “Communication monitoring” on page 20, communication monitoring is activated.

If the status of exclusive operating rights changes again, the timeout value for communication monitoring must be reset to 0. Monitoring is deactivated as a result.

Subsequently, the operating rights are no longer exclusive and another control section can obtain the operating rights, if required.

See also the chapter “Operator and viewer” in the operating manual accompanying your constant temperature equipment.

7.2.3 Communication monitoring

The write command with the ID 34 allows you to set the timeout value for communication monitoring. If the selected value is greater than 0 seconds, communication monitoring is activated for the interface. The timeout value can also be set from the device menu of the interface module.

If a command is not sent via the interface for the duration of the preset timeout, the timeout has expired and a disconnection is detected.

Valid for Integral IN, Variocool NRTL and PRO constant temperature equipment

In this case, *Alarm 22* is triggered and the device:

- a) - Stops the pump, the heater and the refrigerating machine if the Safe Mode function is deactivated.
- b) - Starts Safe Mode if the Safe Mode function is activated.

Valid for Variocool constant temperature equipment

In this case, *Warning 503* is triggered and the device sets the stored safety set point once (write command *ID 32*, factory setting 20 °C) and continues to control the temperature with this operating status.

It is therefore necessary to send any messages periodically so that the monitoring feature recognizes that communication is still active.

If the status of communication monitoring changes again, the timeout value for communication monitoring must be reset to 0. Monitoring is deactivated as a result.

The timeout value can also be adjusted from the device menu.

7.2.4 Read commands

The interface module recognizes the following read commands, which you can use to retrieve operating data of the constant temperature equipment.

Table 5: Temperature

ID	Function	Unit, resolution	Command
2	Temperature set point	[°C]	IN_SP_00
3	Bath temperature (outflow temperature)	[°C], 0.01 °C	IN_PV_00
4	Bath temperature (outflow temperature)	[°C], 0.001 °C	IN_PV_10
5	Controlled temperature (internal / external Pt / external analog / external serial)	[°C]	IN_PV_01
7	External temperature T_E (Pt)	[°C]	IN_PV_03
8	External temperature T_E (analog input)	[°C]	IN_PV_04
14	External temperature T_E (Pt)	[°C], 0.001 °C	IN_PV_13
25	Overtemperature turn off point T_{Max}	[°C]	IN_SP_03
27	Limitation of outflow temperature T_{iH} (upper limit)	[°C]	IN_SP_04
29	Limitation of outflow temperature T_{iH} (lower limit)	[°C]	IN_SP_05
33	Set temperature T_{set} in Safe Mode (Safe set point in case of communication interruption).	[°C]	IN_SP_07
158	Actuating signal of master controller in case of external control	[°C]	IN_PV_11

ID	Function	Unit, resolution	Command
162	Overtemperature turn off point, tank (only for Integral IN XT)	[°C]	IN_SP_12
163	Overtemperature turn off point, outlet (only for Integral IN P)	[°C]	IN_SP_13

Table 6: Pump

ID	Function	Unit	Command
6	Outflow pressure / pump pressure, relative to the atmosphere	[bar]	IN_PV_02
12	Through-flow of the pump (MID flow controller must be connected)	[l/min]	IN_PV_07
18	Pump power stage (only applies to Integral IN XT/P and PRO)	[-]	IN_SP_01
31	Outflow pressure / pump pressure setpoint (only applies to Integral IN XT/P with pressure control settings)	[bar]	IN_SP_06
37	Through-flow control set point (MID flow controller must be connected)	[l/min]	IN_SP_09
71	Status of through-flow control: 0 = off / 1 = on	[-]	IN_MODE_05
154	Outflow pressure of flow controller, relative to the atmosphere (MID flow controller must be connected)	[bar]	IN_PV_09
156	Pressure limitation set point with active through-flow control (MID flow controller must be connected)	[bar]	IN_SP_10
157	Overpressure turn off point with active through-flow control (MID flow controller must be connected)	[bar]	IN_SP_11
160	Valve position of the flow controller (MID flow controller must be connected)	[%]	IN_PV_12

Table 7: Fill level

ID	Function	Unit	Command
9	Bath level (fill level)	[-]	IN_PV_05

Table 8: Actuating signal

ID	Function	Unit, resolution	Command
11	Resolution of controller actuating signal in per mill – negative value → device is cooling – positive value → device is heating	[%]	IN_PV_06
13	Controller actuating signal in watts – negative value → device is cooling – positive value → device is heating	[W]	IN_PV_08

Table 9: Cooling

ID	Function	Unit	Command
24	Cooling mode: 0 = off / 1 = on / 2 = automatic	[-]	IN_SP_02

Table 10: Safety

ID	Function	Unit	Command
35	Timeout communication via interface (1 – 99 seconds; 0 = Off)	[s]	IN_SP_08
73	Status of Safe Mode: 0 = off (inactive) / 1 = on (active)	[-]	IN_MODE_06

Table 11: Control parameters

ID	Function	Unit	Command
39	Control parameter Xp	[-]	IN_PAR_00
41	Control parameter Tn (181 = Off)	[s]	IN_PAR_01
43	Control parameter Tv	[s]	IN_PAR_02
45	Control parameter Td	[s]	IN_PAR_03
47	Control parameter KpE	[-]	IN_PAR_04
49	Control parameter TnE	[s]	IN_PAR_05
51	Control parameter TvE	[s]	IN_PAR_06
53	Control parameter TdE	[s]	IN_PAR_07
55	Correction limitation	[K]	IN_PAR_09
57	Control parameter XpF	[-]	IN_PAR_10
61	Control parameter Prop_E	[K]	IN_PAR_15

Table 12: Control

ID	Function	Unit	Command
59	Setpoint offset	[K]	IN_PAR_14
67	Control in control variable X: 0 = internal / 1 = external Pt / 2 = external analog / 3 = external serial / 5 = external Ethernet / 6 = external EtherCAT / 7 = external Pt 2 (only for Integral)	[-]	IN_MODE_01
69	Offset source X for set point: 0 = normal / 1 = external Pt / 2 = external analog / 3 = external serial / 5 = external Ethernet / 6 = external EtherCAT / 7 = external Pt 2 (only for Integral)	[-]	IN_MODE_04

Table 13: Rights

ID	Function	Unit	Command
63	Status of Master keyboard: 0 = free / 1 = blocked	[-]	IN_MODE_00
65	Status of remote control keyboard: 0 = free / 1 = blocked Remote control must be connected	[-]	IN_MODE_03

Table 14: Status

ID	Function	Unit	Command
75	Status of standby: 0 = Device is switched on / 1 = Device is switched off	[-]	IN_MODE_02
107	Device type (e.g.: "INT" or "INXT")	[-]	TYPE
130	Device status: 0 = OK / -1 = fault	[-]	STATUS
131	<p>Fault diagnosis; a 7-digit answer in the format XXXXXXXX is output, whereby each character X contains fault information (0 = no fault / 1 = fault).</p> <p>The following information is defined for the seven places of the answer format:</p> <ul style="list-style-type: none"> ■ 1st character = Error ■ 2nd character = Alarm ■ 3rd character = Warning ■ 4th character = Overtemperature ■ 5th character = Low level ■ 6th character = 0 (with alarm setting: high level) ■ 7th character = External control value missing 	[-]	STAT
161	Serial number, alphanumerical (10 characters)	[-]	SERIAL_NO

Table 15: Programmer

ID	Function	Unit	Command
77	Program used as a basis for further commands	[-]	RMP_IN_04
85	Programmer segment	[-]	RMP_IN_00_[seg. no.]
88	Current segment number	[-]	RMP_IN_01
90	Number of preset program sequences	[-]	RMP_IN_02
92	Current program loop	[-]	RMP_IN_03
94	Currently running program (0 = no program currently running)	[-]	RMP_IN_05

Table 16: Contact input / output

ID	Function	Unit	Command
96	Contact input 1: 0 = open / 1 = closed	[-]	IN_DI_01
98	Contact input 2: 0 = open / 1 = closed	[-]	IN_DI_02
100	Contact input 3: 0 = open / 1 = closed	[-]	IN_DI_03
102	Contact output 1: 0 = open / 1 = closed	[-]	IN_DO_01
104	Contact output 2: 0 = open / 1 = closed	[-]	IN_DO_02
106	Contact output 3: 0 = open / 1 = closed	[-]	IN_DO_03

Table 17: SW version

ID	Function	Unit	Command
108	Control system	[-]	VERSION_R
109	Protection system	[-]	VERSION_S
110	Remote control (Command) (remote control unit must be present)	[-]	VERSION_B
111	Cooling system (only for devices with active cooling)	[-]	VERSION_T
112	Analog interface module (interface module must be present)	[-]	VERSION_A
113	Through-flow control (MIDxx) (flow controller must be present)	[-]	VERSION_A.1
114	RS 232/485 interface module or Profibus/Profinet/CAN (interface module must be present)	[-]	VERSION_V
115	Ethernet interface module (interface module must be present)	[-]	VERSION_Y
116	EtherCAT interface module (interface module must be present)	[-]	VERSION_Z
117	Contact interface module (interface module must be present)	[-]	VERSION_D
118	Solenoid valve for cooling water (solenoid valve must be fitted) (only applies to Integral IN T)	[-]	VERSION_M.0
124	Pump 0 (applies to Integral IN XT/P)	[-]	VERSION_P.0
125	Pump 1 (applies to Integral IN XT/P, but only to devices with a double pump or supplementary pump)	[-]	VERSION_P.1
126	Heating system 0	[-]	VERSION_H.0
127	Heating system 1 (only applies to devices with a heater > 16 kW)	[-]	VERSION_H.1

ID	Function	Unit	Command
128	External Pt interface 0 (an external temperature module must be present)	[–]	VERSION_E
129	External Pt interface 1 (a second external temperature module must be present)	[–]	VERSION_E_1

Table 18: Pressure overlay

ID	Function (only applies to devices with pressure overlay)	Unit	Command
165	Set pressure for pressure overlay (applies to Integral IN P)	[bar]	IN_SP_14
166	Tank pressure of pressure overlay (applies to Integral IN P)	[bar]	IN_PV_14
168	Pressure overlay hysteresis (applies to Integral IN P)	[bar]	IN_SP_15

Table 19: Filling system

ID	Function	Unit	Command
169	Status of the filling and draining unit (0 = Init., 1 = Standby, 2 = Pre-temp. ctrl., 3 = Drain, 4 = Change application, 5 = Leak test, 6 = Fill, 7 = Pause, 8 = Refill, 9 = Decommission) Caution! Filling and draining unit must be connected.	[–]	IN_MODE_07
172	Draining temperature	[°C]	IN_SP_16
174	Pressure specification for leak test	[bar]	IN_SP_17
176	Leak test duration	[s]	IN_PAR_16
178	Maximum permissible pressure difference during leak test	[bar]	IN_PAR_17
180	Venting time at the end of the filling process	[s]	IN_PAR_18
182	Target filling level of the expansion tank of the constant temperature equipment during the filling process	[–]	IN_SP_18
184	Status of automatic filling device for the filling and draining unit tank (0 = off, 1 = on)	[–]	IN_MODE_08
186	Start of automatic filling device (lower fill limit -> refilling on)	[%]	IN_PAR_19
188	Stop of automatic filling device (upper fill limit -> refilling off)	[%]	IN_PAR_20
189	Filling/draining system outflow pressure	[bar]	IN_PV_15
190	Filling/draining system tank level	[%]	IN_PV_16
Not with Integral IN T			

7.2.5 Write commands



Addition to timeout and operator privileges:

No exclusive operator privileges are set when setting the timeout (ID 34 + 35). If necessary, exclusive operator privileges must be set manually using a command (ID 201 + 202). However, the timeout (timeout \neq 0) must be actively functioning to switch on exclusive operator privileges. This ensures that the constant temperature equipment retains its operator privileges if the connection is interrupted.

The interface module recognizes the following write commands, which you can use to transfer values to the constant temperature equipment.

Table 20: Temperature

ID	Function	Unit	Command
1	Temperature set point	[°C]	OUT_SP_00_XXX.XX
15	Actual value of external temperature (via interface)	[°C]	OUT_PV_05_XXX.XX
26	Limitation of outflow temperature TiH (upper limit)	[°C]	OUT_SP_04_XXX.XX
28	Limitation of outflow temperature TiH (lower limit)	[°C]	OUT_SP_05_XXX.XX
32	Temperature set point T_{set} in Safe Mode	[°C]	OUT_SP_07_XXX.XX

Table 21: Pump

ID	Function	Unit	Command
17	Pump power stage 1 – 8 (applies to Integral IN XT/P)	[–]	OUT_SP_01_XXX
30	Set pressure (with pressure control settings) (applies to Integral IN XT/P)	[bar]	OUT_SP_06_X.XX
36	Through-flow control set point (MID flow controller must be connected)	[l/min]	OUT_SP_09_X.XX

ID	Function	Unit	Command
70	Activate through-flow control: 0=Switch = switch off / 1 = switch on	[–]	OUT_MODE_05.X
155	Pressure limitation set point with active through-flow control (MID flow controller must be connected and equipped with an integrated pressure sensor)	[bar]	OUT_SP_10.X.X

Table 22: Cooling

ID	Function	Unit	Command
23	Cooling mode: 0 = off / 1 = on / 2 = automatic	[–]	OUT_SP_02.XXX

Table 23: Safety

ID	Function	Unit	Command
34	Timeout communication via interface (1 – 99 seconds; 0 = Off)	[s]	OUT_SP_08.XXX
72	Activate Safe Mode	[–]	OUT_MODE_06.1

Table 24: Control parameters

ID	Function	Unit	Command
38	Control parameter Xp	[–]	OUT_PAR_00.XX.X
40	Control parameter Tn (5 – 180 s; 181 = Off)	[s]	OUT_PAR_01.XXX
42	Control parameter Tv	[s]	OUT_PAR_02.XXX
44	Control parameter Td	[s]	OUT_PAR_03.XX.X
46	Control parameter KpE	[–]	OUT_PAR_04.XX.XX
48	Control parameter TnE (0 – 9000 s; 9001 = Off)	[s]	OUT_PAR_05.XXXX
50	Control parameter TvE (5 = Off)	[s]	OUT_PAR_06.XXXX
52	Control parameter TdE	[s]	OUT_PAR_07.XXXX.X
54	Correction limitation	[K]	OUT_PAR_09.XXX.X
56	Control parameter XpF	[–]	OUT_PAR_10.XX.X
60	Control parameter Prop_E	[K]	OUT_PAR_15.XXX

Table 25: Control

ID	Function	Unit	Command
58	Setpoint offset	[K]	OUT_PAR_14.XXX.X
66	Control in control variable X: 0 = internal / 1 = external Pt / 2 = external analog / 3 = external serial / 5 = external Ethernet / 6 = external EtherCAT / 7 = external Pt 2 (only for Integral)	[–]	OUT_MODE_01.X

ID	Function	Unit	Command
68	Offset source X for set point: 0 = normal / 1 = external Pt / 2 = external analog / 3 = external serial / 5 = external Ethernet / 6 = external EtherCAT / 7 = external Pt 2	[-]	OUT_MODE_04_X

Note (ID 66 and 68): If X = 3, the commands ID 66 and ID 68 cannot be executed in some constant temperature control devices until an external temperature specification has been received (via the command ID 15).

Table 26: Rights

ID	Function	Unit	Command
62	Master keyboard (equivalent to "KEY"): 0 = unlock / 1 = lock	[-]	OUT_MODE_00_X
64	Keyboard remote control unit (command): 0 = unlock / 1 = lock	[-]	OUT_MODE_03_X

Table 27: Status

ID	Function	Unit	Command
74	Switch the device on / off (standby)	[-]	START / STOP

Table 28: Programmer

ID	Function	Unit	Command
76	Select the program for the subsequent commands (X = 1 – 5). The default program is 5 when the constant temperature equipment is switched on. Caution! Executing this command may stop any programs that are currently running.	[-]	RMP_SELECT_X
78	Start programmer	[-]	RMP_START
79	Pause programmer	[-]	RMP_PAUSE
80	Continue programmer (after pause)	[-]	RMP_CONT
81	End programmer	[-]	RMP_STOP
83	Delete program (all segments)	[-]	RMP_RESET
84	Programmer segment	[-]	RMP_OUT_00_[Temp.]-[Time]-[Tol]-[Pumpstep]
89	Number of preset program sequences XXX = 1 - 250; 0 = endless	[-]	RMP_OUT_02_XXX

Table 29: Pressure overlay

ID	Function (only applies to devices with pressure overlay)	Unit	Command
164	Set pressure for pressure overlay (applies to Integral IN P)	[bar]	OUT_SP_14_XXX
167	Pressure overlay hysteresis (applies to Integral IN P)	[bar]	OUT_SP_15_XXX

Table 30: Filling system

ID	Function	Unit	Command
170	Action at the filling and draining unit (0 = No action, 1 = Start draining, 2 = Start filling) Caution! Filling and draining unit must be connected.	[-]	OUT_MODE_07_[value]
171	Draining temperature	[°C]	OUT_SP_16_[value]
173	Pressure specification for leak test	[-]	OUT_SP_17_[value]
175	Leak test duration	[-]	OUT_PAR_16_[value]
177	Maximum permissible pressure difference during leak test	[-]	OUT_PAR_17_[value]
179	Venting time at the end of the filling process	[-]	OUT_PAR_18_[value]
181	Target filling level of the expansion tank of the constant temperature equipment during the filling process	[-]	OUT_SP_18_[value]
183	Status of automatic filling device for the filling and draining unit tank (0 = off, 1 = on)	[-]	OUT_MODE_08_[value]
185	Start of automatic filling device (lower fill limit -> refilling on)	[%]	OUT_PAR_19_[value]
187	Stop of automatic filling device (upper fill limit -> refilling off)	[%]	OUT_PAR_20_[value]
Not with Integral IN T			

7.2.6 Availability of the interface functions

The following table shows the read and write commands that the interface module provides for all compatible product lines of constant temperature equipment.



Special functions (for example, "[ID 6] outflow pressure / pump pressure") are only available if the constant temperature equipment is equipped accordingly. Optional accessories may have to be connected correctly and ready for operation.

ID	Integral IN			Variocool		PRO
	IN...XT *	IN...P*	IN...T *	VC NRTL	VC	
1	✓	✓	✓	✓	✓	✓
2	✓	✓	✓	✓	✓	✓
3	✓	✓	✓	✓	✓	✓
4	✓	✓	✓	✓	✓	✓
5	✓	✓	✓	✓	✓	✓
6	✓	✓	–	–	–	–
7	✓	✓	✓	✓	✓	✓
8	✓	✓	✓	✓	✓	✓
9	✓	✓	✓	✓	✓	✓
11	✓	✓	✓	✓	✓	✓
12	✓	✓	✓	✓	–	–
13	✓	✓	✓	✓	✓	✓
14	✓	✓	✓	✓	✓	✓
15	✓	✓	✓	✓	✓	✓
17	✓	✓	–	–	–	✓
18	✓	✓	–	–	–	✓
23	✓	✓	✓	✓	✓	✓
24	✓	✓	✓	✓	✓	✓
25	✓	✓	✓	–	–	✓
26	✓	✓	✓	✓	✓	✓
27	✓	✓	✓	✓	✓	✓
28	✓	✓	✓	✓	✓	✓
29	✓	✓	✓	✓	✓	✓
30	✓	✓	–	–	–	–
* Equipment type as per rating label						

ID	Integral IN			Variocool		PRO
	IN...XT *	IN...P*	IN...T *	VC NRTL	VC	
31	✓	✓	–	–	–	–
32	✓	✓	✓	✓	✓	✓
33	✓	✓	✓	✓	✓	✓
34	✓	✓	✓	✓	✓	✓
35	✓	✓	✓	✓	✓	✓
36	✓	✓	✓	✓	–	–
37	✓	✓	✓	✓	–	–
38	✓	✓	✓	✓	✓	✓
39	✓	✓	✓	✓	✓	✓
40	✓	✓	✓	✓	✓	✓
41	✓	✓	✓	✓	✓	✓
42	✓	✓	✓	✓	✓	✓
43	✓	✓	✓	✓	✓	✓
44	✓	✓	✓	✓	✓	✓
45	✓	✓	✓	✓	✓	✓
46	✓	✓	✓	✓	✓	✓
47	✓	✓	✓	✓	✓	✓
48	✓	✓	✓	✓	✓	✓
49	✓	✓	✓	✓	✓	✓
50	✓	✓	✓	✓	✓	✓
51	✓	✓	✓	✓	✓	✓
52	✓	✓	✓	✓	✓	✓
53	✓	✓	✓	✓	✓	✓
54	✓	✓	✓	✓	✓	✓
55	✓	✓	✓	✓	✓	✓
56	✓	✓	✓	✓	✓	✓
57	✓	✓	✓	✓	✓	✓
58	✓	✓	✓	✓	✓	✓
59	✓	✓	✓	✓	✓	✓
60	✓	✓	✓	✓	✓	✓
61	✓	✓	✓	✓	✓	✓
62	✓	✓	✓	✓	✓	✓
	* Equipment type as per rating label					

ID	Integral IN			Variocool		PRO
	IN...XT *	IN...P*	IN...T *	VC NRTL	VC	
63	✓	✓	✓	✓	✓	✓
64	✓	✓	✓	✓	✓	✓
65	✓	✓	✓	✓	✓	✓
66	✓	✓	✓	✓	✓	✓
67	✓	✓	✓	✓	✓	✓
68	✓	✓	✓	✓	✓	✓
69	✓	✓	✓	✓	✓	✓
70	✓	✓	✓	✓	–	–
71	✓	✓	✓	✓	–	–
72	✓	✓	✓	✓	–	✓
73	✓	✓	✓	✓	–	✓
74	✓	✓	✓	✓	✓	✓
75	✓	✓	✓	✓	✓	✓
76	✓	✓	✓	✓	–	–
77	✓	✓	✓	✓	–	–
78	✓	✓	✓	✓	–	–
79	✓	✓	✓	✓	–	–
80	✓	✓	✓	✓	–	–
81	✓	✓	✓	✓	–	–
83	✓	✓	✓	✓	–	–
84	✓	✓	✓	✓	–	–
85	✓	✓	✓	✓	–	–
88	✓	✓	✓	✓	–	–
89	✓	✓	✓	✓	–	–
90	✓	✓	✓	✓	–	–
92	✓	✓	✓	✓	–	–
94	✓	✓	✓	✓	–	–
96	✓	✓	✓	✓	✓	✓
98	✓	✓	✓	✓	✓	✓
100	✓	✓	✓	✓	✓	✓
102	✓	✓	✓	✓	✓	✓
104	✓	✓	✓	✓	✓	✓
	* Equipment type as per rating label					

ID	Integral IN			Variocool		PRO
	IN...XT *	IN...P*	IN...T *	VC NRTL	VC	
106	✓	✓	✓	✓	✓	✓
107	✓	✓	✓	✓	✓	✓
108	✓	✓	✓	✓	✓	✓
109	✓	✓	✓	✓	✓	✓
110	✓	✓	✓	✓	✓	✓
111	✓	✓	✓	✓	✓	✓
112	✓	✓	✓	✓	✓	✓
113	✓	✓	✓	✓	–	–
114	✓	✓	✓	✓	✓	✓
115	✓	✓	✓	✓	✓	✓
116	✓	✓	✓	✓	✓	✓
117	✓	✓	✓	✓	✓	✓
118	–	–	✓	–	–	✓
119	–	–	–	–	–	✓
120	–	–	–	–	–	–
121	–	–	–	–	–	–
122	–	–	–	–	–	–
124	✓	✓	–	–	–	–
125	✓	✓	–	–	–	–
126	✓	✓	✓	✓	–	–
127	✓	✓	✓	✓	–	–
128	✓	✓	✓	✓	✓	✓
129	✓	✓	✓	✓	–	–
130	✓	✓	✓	✓	✓	✓
131	✓	✓	✓	✓	✓	✓
154	✓	✓	✓	–	–	–
155	✓	✓	✓	–	–	–
156	✓	✓	✓	–	–	–
157	✓	✓	✓	–	–	–
158	✓	✓	✓	✓	–	–
160	–	–	–	–	–	–
161	✓	✓	✓	✓	✓	✓
* Equipment type as per rating label						

ID	Integral IN			Variocool		PRO
	IN...XT *	IN...P*	IN...T *	VC NRTL	VC	
162	✓	–	–	–	–	–
163	–	✓	–	–	–	–
164	–	✓	–	–	–	–
165	–	✓	–	–	–	–
166	–	✓	–	–	–	–
167	–	✓	–	–	–	–
168	–	✓	–	–	–	–
169	✓	✓	–	–	–	–
170	✓	✓	–	–	–	–
171	✓	✓	–	–	–	–
172	✓	✓	–	–	–	–
173	✓	✓	–	–	–	–
174	✓	✓	–	–	–	–
175	✓	✓	–	–	–	–
176	✓	✓	–	–	–	–
177	✓	✓	–	–	–	–
178	✓	✓	–	–	–	–
179	✓	✓	–	–	–	–
180	✓	✓	–	–	–	–
181	✓	✓	–	–	–	–
182	✓	✓	–	–	–	–
183	✓	✓	–	–	–	–
184	✓	✓	–	–	–	–
185	✓	✓	–	–	–	–
186	✓	✓	–	–	–	–
187	✓	✓	–	–	–	–
188	✓	✓	–	–	–	–
189	✓	✓	–	–	–	–
190	✓	✓	–	–	–	–
	* Equipment type as per rating label					

7.2.7 Error messages

The following is a description of the error messages of the interface modules.
The string *ERR_X* or *ERR_XX* is output after an incorrect command.

Error	Description
ERR_2	Incorrect entry (for example, buffer overflow)
ERR_3	Wrong command
ERR_5	Syntax error in value
ERR_6	Impermissible value
ERR_8	Module or value not available
ERR_30	Programmer, all segments occupied
ERR_31	Not possible to specify a set point value. The "Setpoint offset" function is active.
ERR_32	$TiH \leq TiL$
ERR_33	External sensor missing
ERR_34	Analog value not present
ERR_35	Automatically configured
ERR_36	Not possible to specify set point, programmer is running or has been paused
ERR_37	Not possible to start programmer (analog set point value input is ON)
ERR_38	The operator does not have the privileges to execute the command. Another control section has exclusive operating privileges, which means that writing via this interface is not permitted.
ERR_39	Operation is not permitted. Safe Mode is active.
ERR_40	Operation is not permitted. Safe Mode is switched off.
ERR_41	Operation is not permitted. Constant temperature equipment is in error status.

7.3 Control and automation software

Terminal

A terminal program can be used to communicate with the constant temperature equipment. For example, the freeware *RealTerm*, which can be downloaded from the following address: <https://realterm.sourceforge.io/>

The following settings are required to establish a connection to the constant temperature equipment:

1. Start the terminal program on the connected system.
2. Open the *Port* tab:
 - Select the preset baud rate in the *Baud* field.
 - Select the relevant COM port in the *Port* field.
 - Press *Open* to confirm your selection.




Fig. 10: Example in RealTerm: selecting the baud rate and COM port

3. Activate the option *Half Duplex* in the *Display* tab.




Fig. 11: Setting the transmission type

4. Open the *Send* tab and activate the options *+CR* and/or *+LF* in the *EOL* area.
5. Send a test command such as the read command "TYPE" to the constant temperature equipment.
 - If the device type designation, for example "ECO", is received in response, the connection has been set up correctly.




Fig. 12: Setting command lines to end automatically with CR/LF

LabVIEW

The program development tool LabVIEW® from National Instruments <https://www.ni.com/de-de/shop/labview.html> can be used to create convenient, personalized control software or automation software for operating constant temperature equipment. In order to cater for the programming needs of the interface used here, drivers designed specially for LABVIEW® can be downloaded free of charge from the download area of its LAUDA website: <https://www.lauda.de/de/services/download-center/filter/Software>

8 Maintenance

The interface module is maintenance-free.

Any dust and dirt deposits should be cleaned from the connections on the interface module on a regular basis, especially if the interfaces are not being used.



WARNING!

Live parts in contact with cleaning agent

Electric shock, material damage

- Disconnect the device from the mains supply before starting any cleaning work.
- Water and other fluids should not be allowed to enter the device.



NOTICE!

Repairs performed by unauthorized persons

Material damage

- Only specialized personnel are permitted to carry out repairs.

1. Use a damp cloth or brush to remove any dust and dirt deposits.
2. When using compressed air: Always set a low working pressure to prevent mechanical damage to the connections.



If you have any questions about technical modifications, please contact LAUDA Service, see ↗ Chapter 1.6 “Contact LAUDA” on page 7.

9 Faults

If a fault occurs, the interface distinguishes between different message types, e.g. alarms, errors and warnings. The procedure for rectifying a fault depends on the device. Follow the corresponding instructions in the operating manual accompanying the constant temperature equipment.



If you are unable to rectify a fault, please contact LAUDA Service, see ↗ Chapter 1.6 “Contact LAUDA” on page 7.

9.1 Alarm

The RS 232/485 interface recognizes the following alarm messages.

Table 31: RS 232/485 alarm messages

Code	Meaning
11	Triggers when the command with ID 15 (actual value external temperature) has not been received for several seconds while the system is regulating to the "external serial" control variable.
22	Disconnection detected. There was no communication for a period longer than the preset timeout.

9.2 Error

The RS 232/485 interface recognizes the following error messages.

Table 32: RS 232/485 error messages

Code *	Meaning
501 – 504, 507, 508	Interface module hardware faulty. Contact the LAUDA department.
505	Internal 24 V voltage of the interface module is too low.
506	Internal 24 V voltage of the interface module is too high.

9.3 Warning

The RS 232/485 interface recognizes the following warning messages.

Table 33: RS 232/485 warning messages

Code	Meaning
501	Internal communication overloaded.
502	Unexpected reset. Contact LAUDA Service if the warning occurs multiple times.
503	Disconnection detected. There was no communication for a period longer than the preset timeout. Valid for the Variocool and PRO product lines.
508	Bus system faulty. Contact LAUDA Service if the warning occurs multiple times.
509	Unknown module connected.
510 – 532	Software for specified component outdated. Contact the LAUDA department.

10 Decommissioning





WARNING!
Touching live parts

Electric shock

- Disconnect the device from the power supply before starting any installation work.
- Always observe safety measures against electrostatic discharge.

Decommission the interface module by removing it from the constant temperature equipment:

1. Observe the information in  Chapter 5.1 “Installing the interface module” on page 12. Proceed in reverse order to remove.
2. Always attach the LiBus connecting cable to the inside of the module slot cover.
3. Fit the cover to the vacant module slot to protect the constant temperature equipment against the ingress of dirt.
4. Protect the interface module against static charging before placing it in storage. The storage location must meet the ambient conditions specified in the technical data.
5. If you intend to dispose of the module, please read the information in  “Old device” on page 42 first.

11 Disposal

Packaging

The packaging normally consists of environmentally friendly materials that can be easily recycled when properly disposed of.

1. Dispose of packaging materials in accordance with the applicable disposal guidelines in your region.
2. Comply with the requirements of Directive 94/62/EC (packaging and packaging waste) if disposing of the product in a member state of the EU.

Old device



The device must be properly decommissioned and disposed of at the end of its life cycle.

1. Dispose of the device in accordance with the applicable disposal guidelines in your region.
2. Comply with Directive 2012/19/EU (WEEE Waste of Electrical and Electronic Equipment) if disposing of the product takes place in a member state of the EU.

12 Accessories

Complete connection cables and plugs are available for assembling cables.

Table 34: Accessories

Item	Catalog number
LiBus module box; extension of constant temperature equipment by up to two interface modules with large cover	LCZ 9727
D-Sub 9 socket, complete	EKS 210
RS 232 cable, shielded, 2 m in length	EKS 037
RS 232 cable, shielded, 5 m in length	EKS 057

13 Technical data

Characteristic	Unit	Value/version
Interface module		
Catalog number	[-]	LRZ 926
Size of module slot, W x H	[mm]	51 x 27
External dimensions (excluding connectors), W x H x D	[mm]	56 x 37 x 82
Weight	[kg]	0.1
Operating voltage	[V DC]	24
Maximum current consumption	[A]	0.1
Connection type	[-]	D-SUB socket, 9-pin
Service life	[-]	The interface module is designed for 20,000 operating hours.
Ambient conditions		
Relative humidity	[%]	Maximum relative humidity 80% at an ambient temperature of 31°C, relative humidity linearly decreasing to 50% at 40°C.
Height up to	[m]	2000
Ambient temperature range	[°C]	5 – 40
Temperature range during storage and transport	[°C]	-20 – 60
Degree of pollution according to EN 60664-1 / VDE 0110-1	[-]	2
IP protection level	[IP]	21

14 Declaration of Conformity



EU DECLARATION OF CONFORMITY

Manufacturer: LAUDA DR. R. WOBSE GMBH & CO. KG
Laudaplatz 1, 97922 Lauda-Königshofen, Germany

We hereby declare under our sole responsibility that the products described below

Product line: Accessories **Serial number:** from S220000001

Device type: Interface modules
LRZ 926, LRZ 927, LRZ 928, LRZ 929, LRZ 930, LRZ 931, LRZ 932, LRZ 933

comply with all the relevant provisions of the Directives listed below, based on the design and type of the version we have placed on the market:

- EMC Directive 2014/35/EU
- RoHS Directive 2011/65/EU in conjunction with (EU) 2015/863

The products may only be operated when incorporated or connected in accordance with the operating instructions.

Applicable standards:

- DIN EN IEC 61326-1:2013-07

Authorized representative for the composition of the technical documentation:

Dr. Jürgen Dirscherl, Head of Research & Development

Signed for and on behalf of

LAUDA DR. R. WOBSE GMBH & CO. KG

Lauda-Königshofen, Germany, 06.27.2022



Dr. Alexander Dinger, Head of Quality Management

15 Index

A	
Accessories	43
Alarm	39
C	
Cleaning	38
Communication monitoring	20, 21
Compatibility	6
Contact	7
Copyright	6
D	
Disposal	
Old device	42
Packaging	42
E	
Error	39
Error message	39
Error messages	35
F	
Fault	39
I	
Improper use	5
Intended use	5
Interface functions	18
Availability	31
Read commands	21
Write commands	27
Interface module	
Decommissioning	41
Installation	12
Maintenance	38
Module box	14
Unpacking	10
L	
LabVIEW	37
M	
Menu structure	18
Module	
Compatibility	6
Module box	14
Module generation	17
Module slot	12
Monitoring	20, 21
O	
Operating rights	20
P	
Personnel qualification (overview)	9
Purpose	11
R	
Read commands	21
RS 232/485	
Terminal program	37
RS 232/485 interface	
Contact assignment	15, 17
RS 232/485 module	
Structure	11
S	
Safety information	
General	8
Interface module	9
Service	7
Software	
LabVIEW	37
Terminal program	37
Software update	17
Syntax	18
T	
Technical changes	6
Terminal program	37

U

Update 17

W

Warning 40

Warranty 6

Write commands 27

Manufacturer:

LAUDA DR. R. WOBSE GMBH & CO. KG • Laudaplatz 1 • 97922 Lauda-Königshofen

Telephone: +49 (0)9343 503-0

E-mail: info@lauda.de • Internet: <https://www.lauda.de>