

PRODUCT DATA SHEET



Ultracool UC-0300 SP

Within the Ultracool Maxi range, there are four chillers with cooling outputs from 34.1 up to 64.4 kW which work with one single refrigeration circuit. The five models from 87.9 up to 265 kW of cooling capacities work with two independent refrigeration circuits to provide a backup security. All Maxi models are equipped with scroll compressors, work with R 407C as refrigerant and are suitable for outdoor installation. The internal pipes for the water circuit are made of PP-R (polypropylene random copolymer) and are thermowelded. Besides the main advantage that these connections are absolutely leak free, PP-R is corrosion and frost proof, allow for smaller pressure drops and are long lasting. The models UC-0300 to UC-0650 are also available as UC laser models with pre-configured options included.



Working temperature min.
-5 °C



Working temperature max.
25 °C

Technical Attributes

Ultracool UC-0300 SP

Working temperature min.	-5 °C
Working temperature max.	25 °C
Ambient temperature min.	-15 °C
Ambient temperature max.	45 °C
Temperature stability	2 ±K
Cooling output at 25°C water outlet temperature	50.3 kW
Cooling output at 20°C water outlet temperature	48.2 kW
Cooling output at 15°C water outlet temperature	40.9 kW
Cooling output at 10°C water outlet temperature	34.1 kW
Cooling output at 5°C water outlet temperature	28.2 kW
Cooling output at 0°C water outlet temperature	23.1 kW
Cooling output at -5°C water outlet temperature	18.6 kW
Number of refrigeration circuits	1
Application	external
Power consumption	9.4 kW

LAUDA DR. R. WOBSEY GMBH & CO. KG
Pfarrstraße 41/43 · 97922 Lauda-Königshofen
Postfach 1251 · 97912 Lauda-Königshofen · DE

T +49 (0) 9343 503-0 · F +49 (0) 9343 503-222
info@lauda.de · www.lauda.de
WEEE-Reg.-Nr.: DE 66 42 40 57

Kommanditgesellschaft: Sitz Lauda-Königshofen
Registergericht Mannheim · HRA 560069

Persönlich haftende Gesellschafterin:
LAUDA DR. R. WOBSEY Verwaltungs-GmbH
Sitz Lauda-Königshofen
Registergericht Mannheim · HRB 560226

Geschäftsführer:
Dr. Gunther Wobser (Vors.), Dr. Mario Englert
Dr. Marc Stricker
Beirat: Dr. Gerhard Wobser

PRODUCT DATA SHEET

Ultracool UC-0300 SP

Technical Attributes	Ultracool UC-0300 SP
Pump pressure max.	4.7 bar
Pump pressure nominal	3.9 bar
Pump flow max. (pressure)	230 L/min
Pump flow nominal	98 L/min
Pump connection thread	HT DN40
Volume water reservoir	200 L
Dimensions (WxDxH) in mm	1005x1565x1965
Noise level	50.2 dB(A)
Max. fuse	40 A

LAUDA DR. R. WOBSEY GMBH & CO. KG
 Pfarrstraße 41/43 · 97922 Lauda-Königshofen
 Postfach 1251 · 97912 Lauda-Königshofen · DE

T +49 (0) 9343 503-0 · F +49 (0) 9343 503-222
 info@lauda.de · www.lauda.de
 WEEE-Reg.-Nr.: DE 66 42 40 57

Kommanditgesellschaft: Sitz Lauda-Königshofen
 Registergericht Mannheim · HRA 560069

Persönlich haftende Gesellschafterin:
 LAUDA DR. R. WOBSEY Verwaltungs-GmbH
 Sitz Lauda-Königshofen
 Registergericht Mannheim · HRB 560226

Geschäftsführer:
 Dr. Gunther Wobser (Vors.), Dr. Mario Englert
 Dr. Marc Stricker
 Beirat: Dr. Gerhard Wobser