

# PRODUCT DATA SHEET



## Ultracool UC-1700 SP

The five models of the Ultracool Maxi circulation chillers from 87.9 up to 265 kW of cooling capacities work with two independent refrigeration circuits to provide a backup security. All Maxi models are equipped with scroll compressors, work with R 407C as refrigerant and are suitable for outdoor installation. The internal pipes for the water circuit are made of PP-R (polypropylene random copolymer) and are thermowelded. Besides the main advantage that these connections are absolutely leak free, PP-R is corrosion and frost proof, allow for smaller pressure drops and are long lasting.



Working temperature min.  
-5 °C



Working temperature max.  
25 °C

Technical Attributes	Ultracool UC-1700 SP
Working temperature min.	-5 °C
Working temperature max.	25 °C
Ambient temperature min.	-15 °C
Ambient temperature max.	45 °C
Temperature stability	2 ±K
Cooling output at 25°C water outlet temperature	228.4 kW
Cooling output at 20°C water outlet temperature	228.4 kW
Cooling output at 15°C water outlet temperature	205.9 kW
Cooling output at 10°C water outlet temperature	175.7 kW
Cooling output at 5°C water outlet temperature	144.6 kW
Cooling output at 0°C water outlet temperature	115.6 kW
Cooling output at -5°C water outlet temperature	90.8 kW
Number of refrigeration circuits	2
Application	external
Power consumption	54.9 kW

LAUDA DR. R. WOBSEY GMBH & CO. KG  
Pfarrstraße 41/43 · 97922 Lauda-Königshofen  
Postfach 1251 · 97912 Lauda-Königshofen · DE  
  
T +49 (0) 9343 503-0 · F +49 (0) 9343 503-222  
info@lauda.de · www.lauda.de  
WEEE-Reg.-Nr.: DE 66 42 40 57

Kommanditgesellschaft: Sitz Lauda-Königshofen  
Registergericht Mannheim · HRA 560069  
  
Persönlich haftende Gesellschafterin:  
LAUDA DR. R. WOBSEY Verwaltungs-GmbH  
Sitz Lauda-Königshofen  
Registergericht Mannheim · HRB 560226

Geschäftsführer:  
Dr. Gunther Wobser (Vors.), Dr. Mario Englert  
Dr. Marc Stricker  
Beirat: Dr. Gerhard Wobser

## PRODUCT DATA SHEET

### Ultracool UC-1700 SP

Technical Attributes	Ultracool UC-1700 SP
Pump pressure max.	5 bar
Pump pressure nominal	3.6 bar
Pump flow max. (pressure)	750 L/min
Pump flow nominal	494 L/min
Pump connection thread	Rp 2 1/2"
Volume water reservoir	500 L
Dimensions (WxDxH) in mm	1660x3400x2090
Noise level	61.3 dB(A)
Max. fuse	150 A

LAUDA DR. R. WOBSEY GMBH & CO. KG  
Pfarrstraße 41/43 · 97922 Lauda-Königshofen  
Postfach 1251 · 97912 Lauda-Königshofen · DE

T +49 (0) 9343 503-0 · F +49 (0) 9343 503-222  
info@lauda.de · www.lauda.de  
WEEE-Reg.-Nr.: DE 66 42 40 57

Kommanditgesellschaft: Sitz Lauda-Königshofen  
Registergericht Mannheim · HRA 560069

Persönlich haftende Gesellschafterin:  
LAUDA DR. R. WOBSEY Verwaltungs-GmbH  
Sitz Lauda-Königshofen  
Registergericht Mannheim · HRB 560226

Geschäftsführer:  
Dr. Gunther Wobser (Vors.), Dr. Mario Englert  
Dr. Marc Stricker  
Beirat: Dr. Gerhard Wobser