

PRODUCT DATA SHEET

Ultracool UC-2400 SP

The five models of the Ultracool Maxi circulation chillers from 87.9 up to 265 kW of cooling capacities work with two independent refrigeration circuits to provide a backup security. All Maxi models are equipped with scroll compressors, work with R 407C as refrigerant and are suitable for outdoor installation. The internal pipes for the water circuit are made of PP-R (polypropylene random copolymer) and are thermowelded. Besides the main advantage that these connections are absolutely leak free, PP-R is corrosion and frost proof, allow for smaller pressure drops and are long lasting.



Working temperature min.
-5 °C



Working temperature max.
25 °C

Technical Attributes	Ultracool UC-2400 SP
Working temperature min.	-5 °C
Working temperature max.	25 °C
Ambient temperature min.	-15 °C
Ambient temperature max.	45 °C
Temperature stability	2 ±K
Cooling output at 25°C water outlet temperature	336.9 kW
Cooling output at 20°C water outlet temperature	336.9 kW
Cooling output at 15°C water outlet temperature	308.8 kW
Cooling output at 10°C water outlet temperature	265 kW
Cooling output at 5°C water outlet temperature	223.1 kW
Cooling output at 0°C water outlet temperature	182.8 kW
Cooling output at -5°C water outlet temperature	148.2 kW
Number of refrigeration circuits	2
Application	external
Power consumption	71.4 kW

LAUDA DR. R. WOBSEY GMBH & CO. KG
Pfarrstraße 41/43 · 97922 Lauda-Königshofen
Postfach 1251 · 97912 Lauda-Königshofen · DE

T +49 (0) 9343 503-0 · F +49 (0) 9343 503-222
info@lauda.de · www.lauda.de
WEEE-Reg.-Nr.: DE 66 42 40 57

Kommanditgesellschaft: Sitz Lauda-Königshofen
Registergericht Mannheim · HRA 560069

Persönlich haftende Gesellschafterin:
LAUDA DR. R. WOBSEY Verwaltungs-GmbH
Sitz Lauda-Königshofen
Registergericht Mannheim · HRB 560226

Geschäftsführer:
Dr. Gunther Wobser (Vors.), Dr. Mario Englert
Dr. Marc Stricker
Beirat: Dr. Gerhard Wobser

PRODUCT DATA SHEET

Ultracool UC-2400 SP

Technical Attributes	Ultracool UC-2400 SP
Pump pressure max.	5.9 bar
Pump pressure nominal	3.8 bar
Pump flow max. (pressure)	1160 L/min
Pump flow nominal	733 L/min
Pump connection thread	DIN-2566 DN80
Volume water reservoir	500 L
Dimensions (WxDxH) in mm	1660x3585x2090
Max. fuse	200 A

LAUDA DR. R. WOBSEY GMBH & CO. KG
 Pfarrstraße 41/43 · 97922 Lauda-Königshofen
 Postfach 1251 · 97912 Lauda-Königshofen · DE

T +49 (0) 9343 503-0 · F +49 (0) 9343 503-222
 info@lauda.de · www.lauda.de
 WEEE-Reg.-Nr.: DE 66 42 40 57

Kommanditgesellschaft: Sitz Lauda-Königshofen
 Registergericht Mannheim · HRA 560069

Persönlich haftende Gesellschafterin:
 LAUDA DR. R. WOBSEY Verwaltungs-GmbH
 Sitz Lauda-Königshofen
 Registergericht Mannheim · HRB 560226

Geschäftsführer:
 Dr. Gunther Wobser (Vors.), Dr. Mario Englert
 Dr. Marc Stricker
 Beirat: Dr. Gerhard Wobser